

2020 Buick Truck Enclave AWD V6-3.6L
Vehicle > Transmission and Drivetrain > Automatic Transmission/Transaxle
PARTS AND LABOR

Parts	OEM PART #	PRICE	^
Automatic Transaxle			
Filter	24297793	30.13	
Includes Seal Kit.			
Input Sensor	24298199	15.75	
Output Sensor	24295280	11.35	
Pan Gasket	24044908	25.85	
Trans Controller	24046814	242.66	
Automatic Transmission			
Transmission	19419489	4054.59	
Mount			
Front	84883991	118.35	
Rear	85157579	92.78	
Side	84382027	152.66	
Case & Related Parts			
Drive Plate	12727438	80.40	
Manual Shaft Seal	24256576	7.18	
Side Cover	24049671	42.69	
Side Cover Gasket	24044908	25.85	
Torque Converter			
From 8/20/2018	24293119	317.43	
Oil Cooler			
Hoses			
Inlet	84335372	55.01	
Outlet	84335376	58.70	
Line			
See Oil Cooler Hoses		0.00	
Valve Body			
Valve Body	24297660	545.82	
Gear Shift Control			
Gear Shift Assembly	84291879	242.09	
Shift Control Cable	84595308	0.00	
Labor	SKILL WARRANTY STANDARD ^		
Change			
Automatic Transaxle			
Trans Fluid, Change	C	0.9	1.0
Remove & Replace			
Automatic Transaxle			
Filter, R&R	C	0.0	3.8
Input Sensor, R&R	B	0.0	1.0
Output Sensor, R&R	B	12.5	16.8
Trans Controller, R&R	B	0.0	0.7
Automatic Transmission			
Mount, R&R			
Front	B	0.5	0.7
Left	B	4.5	5.6
Rear	B	1.1	1.5
Transmission, R&R	A	0.0	16.7
Transmission, R&R			
NOTE (Optional Labor)			

To Flush Cooler Lines, Add			0.6	🔗
To R&R Driveplate, Add			0.4	🔗
To R&R Torque Converter,				
Add			0.2	🔗
Case & Related Parts				
Drive Plate, R&R	A	0.0	17.1	🔗
Manual Shaft Seal, R&R	A	0.0	15.0	🔗
Side Cover Gasket, R&R	A	0.0	3.8	🔗
Side Cover, R&R	A	3.0	3.8	🔗
Torque Converter, R&R	A	0.0	16.9	🔗
Gear Shift Control				
Gear Shift Assembly, R&R	B	0.0	1.3	🔗
Shift Control Cable, R&R	B	0.0	1.5	🔗
Oil Cooler				
Hoses, R&R				
See Line, R&R.		0.0		🔗
Line, R&R				
Auxiliary	C	1.5	1.8	🔗
Thermal Bypass Valve	C	0.6	0.8	🔗
With Heavy Duty Cooler				
Inlet	C	3.8	4.8	🔗
Outlet	C	3.4	4.4	🔗
Without Heavy Duty Cooler				
Inlet	C	3.0	4.2	🔗
Outlet	C	3.0	4.2	🔗
Valve Body				
Valve Body, R&R	A	0.0	13.3	🔗
<i>Includes: Radiator R&R.</i>				
Diagnosis				
Automatic Transmission				
Oil Leak, Diagnosis	B	0.0	0.5	🔗
<i>Includes: Clean And Dry Outside Of Case And Operating Unit To Determine Point Of Leakage.</i>				
Transmission, Diagnosis	A	0.0	1.8	🔗
<i>Includes: Time To Hook-Up And Disconnect Test Equipment. Checking System For Fault Codes, Road Test And Hydraulic Pressure Test As Required.</i>				
Remove & Install				
Automatic Transmission				
Transmission, R&I	A	0.0	16.7	🔗
Transmission, R&I				
NOTE (Optional Labor)				
To R&R Driveplate, Add			0.4	🔗
To R&R Torque Converter,				
Add			0.2	🔗
Overhaul				
Automatic Transmission				
Transmission, Overhaul	A	0.0	23.7	🔗
Transmission, Overhaul				
NOTE (Optional Labor)				
To Flush Cooler Lines, Add			0.6	🔗
To Overhaul Valve Body, Add			1.6	🔗